GGG2020 at BIRA-IASB

Minqiang Zhou

September 4, 2020

1 Installation

The ggg2020 has been installed in /bira-iasb/projects/FTIR/retrievals/operational/tools/ggg2020.

The hg setting and some preparations

- 1) hg clone https://parkfalls.gps.caltech.edu/tccon/stable/hg/ggg-stable/ $\rm ggg2020$
- $2)\ download\ miniconda 3\ here:\ https://docs.conda.io/en/latest/miniconda.html;\ then\ install\ it$
- 3) add GGGPATH in the .bashrc or .profile

The detail instruction is available at tccon wiki.




Figure 1: GGG2020 download.

Steps

STEP 1: cd \$GGGPATH/install

STEP 2: ./master.sh 4 (you will crash, as you do not have the write to install the python lib in the default folder)

STEP 3: change the install/clone_netcdf_writer.sh

(do not overwrite again as you do not download the tccon_netcdf python code again; I already change the code in the ggg2020/install folder)

STEP 4: change the src/tccon_netcdf (install the python lib to a user defined place: -prefix)
STEP 5: add the prefix folder to install the python lib, for example, ggg2020/python_tool/lib/python3.7/site-packages
STEP 6: cd \$GGGPATH/install
Type ./master.sh 4
you need to input Y and N
then check the difference.out
the whole process will take about 20 mins

Other notes

- $1) \ GGGPATH should be \ GGGPATH = /bira-iasb/projects/FTIR/retrievals/operational/tools/ggg2020 instead of \ GGGPATH = /home/user/projects/FTIR/retrievals/operational/tools/ggg2020$
- 2) for the conda environment, you might need to install some packages:

conda install -c conda-forge mercurial

conda install -c anaconda setuptools

3) in the src/gfit.f

change write(csfilename,'(a14,i6.6,a4)') 'check_md5sums_',pid, -¿ write(csfilename,'(a14,i7.7,a4)') 'check_md5sums_',pid,

in our system the getpid return 7 int instead of 6

1.1 ggg3 at BIRA-IASB

download by git

make a folder, for example, in ftir_op/python/. git clone https://github.com/zmq814/ggg3_bira.git you will have ggg3_bira folder where you have




Figure 2: ggg3_bira code.

Run ggg3

The code has been tested with the new PC, ada 1...5 using the 19g pack-

```
ages
```

I have define a m19p3geo in the .profile

Step 1. in the terminal, INPUT m
19p3geo $\,$

step 2. in the python section, import ggg3_bira.
retrieve as ${\bf r}$

step3. import datetime as dt

 $step 4.\ stime = dt.datetime(), etime = dt.datetime(), instrument = 'bruker 125 @stdenis' and the statetime () in the statet$

step5. r.main(instrument,stime,etime)